



## CONTACTORES Y RELÉS TÉRMICOS

## Contactores y relés de control

## Contactores 6 - 50 c.a., carga AC-3

Código GF	Código Danfoss	Tipo	Kw/A Diferencial	Contactos principales	Nº conex. cont. Aux.	€
RL0005	037H001531	CI 6	2.2/6.0	3	0-4	27,20
RL0006	037H001831	CI 6	2.2/6.0	4	0-4	31,19
RL0007	037H002131	CI 9	4.0/9.0	3	0-4	28,59
RL0008	037H002231	CI 9	4.0/9.0	4	0-4	34,28
RL0009	037H003131	CI 12	5.5/12.0	3	0-4	32,55
RL0010	037H003231	CI 12	5.5/12.0	4	0-4	38,57
RL0011	037H004931	CI 15	7.5/16.0	3	0-4	39,43
RL0012	037H005031	CI 15	7.5/16.0	4	0-4	48,71
RL0013	037H004131	CI 16	7.5/16.0	3	0-4	44,27
RL0014	037H004531	CI 20	10.0/20.0	3	0-4	51,92
RL0015	037H005131	CI 25	11.0/25.0	3	0-4	62,96
RL0016	037H005531	CI 30	15.0/32.0	3	0-4	73,83
RL0017	037H006131	CI 32	15.0/32.0	3	0-4	97,80
RL0018	037H005631	CI 37	18.5/37.0	3	0-4	110,20
RL0019	037H007131	CI 45	22.0/45.0	3	0-4	134,37
RL0020	037H008031	CI 50	25.0/52.0	3	0-4	147,40



## Accesorios para CI 6-50

## Contactores auxiliares CB

(se pueden acoplar hasta un máximo de 4 contactos aux. por contactor)

Código GF	Código Danfoss	Tipo	Carga (A)	Color	Función del contacto	€
RL0025	037H0110	CB-S	6	Verde	Arranque	5,95
RL0026	037H0117	CB-I	6	Verde	Pulso arranque	6,66
RL0027	037H0111	CB-NO	6	Verde	Cierre. 1 NO	3,46
RL0028	037H0112	CB-NC	6	Rojo	Apertura 1 NC	3,46
RL0029	037H0113	CB-EM	6	Blanco	Cierre rápido	8,37
RL0030	037H0114	CB-LB	6	Azul	Cierre lento	8,37
RL0035	037H0121	CB-NO	6	Blanco	Cierre. 1 NO (rec. dorado)	12,27
RL0036	037H0122	CB-NC	6	Azul	Apertura . 1 NC (rec. dorado)	12,27



## Bobinas de repuesto

Código GF	Código Danfoss	Para contactor	Tensión	€
RL0200	037H6478	CI 6-30	380V 50Hz	12,89
RL0201	037H6462	CI 6-30	24V 50Hz	12,89
RL0202	037H6487	CI 6-30	110V 50Hz	12,89
RL0203	037H6084	CI 32-50	24V 50Hz	18,15
RL0204	037H6472	CI 6-30	220V 50Hz	12,89
RL0205	037H6078	CI 32-50	380V 50Hz	18,15





## CONTACTORES Y RELÉS TÉRMICOS

### Contadores 60 - 85A, c.a., carga AC-3

Código GF	Código Danfoss	Tipo	kW/A Diferencial	Contactos principales	Contactos auxiliares	€
RL0100	037H306132	CI 61	30.0/60.0	3	1-8	207,22
RL0101	037H306232	CI 73	37.0/72.0	3	1-8	260,25
RL0102	037H306332	CI 86	45.0/85.0	3	1-8	331,00



### Contadores 105 - 140A, c.a., carga AC-3

Código GF	Código Danfoss	Tipo	kW/A Diferencial	Contactos principales	Contactos auxiliares	€
RL0104	037H333931	CI 141	75.0/140.0	3	Inc.2-Opc. 2-6	567,41



### Relés Térmicos para contactores CI 32-86

Código GF	Código Danfoss	Tipo	Rango (A) Guardamotor	Rango (A) Arrancador Y / Δ	€
RL0091	047H1013	TI 80	16-23	28-40	72,52
RL0092	047H1014	TI 80	22-32	38-56	80,22
RL0093	047H1015	TI 80	30-45	52-78	82,05
RL0094	047H1016	TI 80	42-63	75-109	115,04
RL0095	047H1017	TI 80	60-80	105-138	134,34
RL0096	047H1018	TI 86	74-85	130-147	151,08



### Relés Térmicos para contactores CI 6-30

Código GF	Código Danfoss	Tipo	Rango (A) Guardamotor	Rango (A) Arrancador Y / Δ	€
RL0050	047H0200	TI 16C	0.13-0.20		33,99
RL0051	047H0201	TI 16C	0.19-0.29		33,99
RL0052	047H0202	TI 16C	0.27-0.42		33,99
RL0053	047H0203	TI 16C	0.4-0.62		33,99
RL0054	047H0204	TI 16C	0.6-0.92		33,99
RL0055	047H0205	TI 16C	0.85-1.30		33,99
RL0056	047H0206	TI 16C	1.2-1.9		33,99
RL0057	047H0207	TI 16C	1.8-2.8	3.2-4.8	33,99
RL0058	047H0208	TI 16C	2.7-4.2	4.7-7.3	33,99
RL0059	047H0209	TI 16C	4.0-6.2	6.9-10.7	33,99
RL0060	047H0210	TI 16C	6.0-9.2	10-16	33,99
RL0061	047H0211	TI 16C	8.0-12	13-20.8	33,99
RL0062	047H0212	TI 16C	11-16	19-27	33,99
RL0063	047H0213	TI 25C	15-20	26-35	44,71
RL0064	047H0214	TI 25C	19-25	33-43	44,71
RL0065	047H0215	TI 30C	24-32	41-55	54,17

